



SERIES 200

USB OUTPUT INTERFACE

- ◆ Connecting series 208 (software is included)
- ◆ Connecting 206 (software is included)

For following series 208
(counter for linear gauge)



208-004-01



208-008-01

For following 206




206-010-01



200-92

Work with series 208 (counter for linear gauge)



code	Plug to product	Products
200-91		for digital indicators with following electronics
200-92		for digital indicators with following electronics